



## Step 6:

Install the bearing mounts, rubber cushions and the bearing flange plates on both sides.



### **IMPORTANT!**

The screws (SSSCM10X75) should be tightened just until the lock washers (WWLM10) are fully compressed. The lock nuts (NNEM10-1.5) should be torqued to 60 ft/lbs.